


## 7. Connecting to PC


Connect device to PC's USB3.0 port using enclosed USB3.0 cable.  
When disconnecting, please use "Hardware Safety Removal" on tray of the O/S.



## 8. Display and Icon



## 9. Using Jog Switch



## 10. Menu Description

- To use Virtual ODD, iso file must be located in the "\_iso" folder of device.
- Enter into menu mode if Jog switch is pressed for 3 seconds.
- If you wants to use the backup software for MS O/S, you can download the software via Zalman web page([www.zalman.com](http://www.zalman.com))

### (1) Main Menu

Mode Select	>	Device Mode setting
Information	>	Check HDD information and firmware information
W-Protection	>	Disable Write Protection / Enable Write Protection
Exit	>	Menu Exit

### (2) Mode Select ("v" is shown in selected mode)

Dual Mode	↔	Both of external HDD and CD-ROM are recognized
VCD Mode	↔	External CD-ROM is recognized. (Useful when OS installing)
HDD Mode	↔	External HDD is recognized. (Useful when connecting other devices except PC)

### (3) Information

HDD Temp	>	Hard disk SMART information
HDD Health	>	Display HDD health info (Good, Bad) - If bad is shown is shown, please check HDD carefully after backup data.
HDD Model Name	>	-----
Firmware Ver.	>	Display device firmware version
Exit	>	Menu Exit