

< BUS 2EASY
< OPEN A
< GND
< OPEN B / CLOSE
< STOP
< FSW OP
< GND
< FSW CL
< +24

< MAIN (PEN-L)
< PRIM TRANSF
< SEC TRANSF

< BATTERY
< MOTOR

< LAMP

< LOCK RELEASE
< LOCK BATTERY
< LOCK

ECC
FCA
RADIO1
RADIO2
ERROR
POWER
SETUP



00E

