



Home Sewing Machine

PARTS REFERENCE LIST

MODEL: FS40/FS40WT

ModerN40E/ModerN50E

ModerN60E/Style-40e

Style-50e/Style-60e

FS70/FS70WTs

FS60s/KD40

CONFIDENTIAL

©2011 Brother Industries, Ltd.
All rights reserved.

Published: Jan.,2010
Revised: May.,2020

MODEL LIST

[illegible]

Country Code & Abbreviation of Country Name

Country Code	Abbr.	Country Name	Country Code	Abbr.	Country Name	Country Code	Abbr.	Country Name
USA/Canada			Europe			Asia/Oceania		
200	USA	America	401	ZAF	South Africa	601	KOR	Korea
251	CAN	Canada	402	EGY	Egypt	603	TWN	Taiwan
			411	MUS	Mauritius	604	HKG	Hong Kong
301	PER	Peru				605	VNM	Vietnam
302	ARG	Argentina	501	IRE	Ireland	606	IDN	Indonesia
303	CHL	Chile	502	DEU	Germany	607	PHL	Philippines
304	PRY	Paraguay	503	BEL	Belgium	608	MYS	Malaysia
305	URY	Uruguay	505	UK	United Kingdom	609	SGP	Singapore
306	BRA	Brazil	506	FRA	France	615	IND	India
307	VEN	Venezuela	507	NOR	Norway	616	THA	Thailand
308	MEX	Mexico	508	NLD	Netherlands	622	CHN	China
309	COL	Colombia	509	AUT	Austria			
310	PAN	Panama	510	GRC	Greece	701	AUS	Australia
318	GTM	Guatemala	511	SWE	Sweden	702	NZL	New Zealand
324	GUF	FR. Guiana	515	ESP	Spain			
330	BRB	Barbados	516	PRT	Portugal	902	ISR	Israel
399	-	Latin America 2&5	517	ITA	Italy	903	SYR	Syria
			519	FIN	Finland	904	TUR	Turkey
			520	CHE	Switzerland	905	JOR	Jordan
			521	DNK	Denmark	906	KWT	Kuwait
			524	MLT	Malta	908	SAU	Saudi Arabia
			550	EEU	East Europe	909	IRQ	Iraq
			556	RUS	Russia	910	IRN	Iran
			599	NEU	North Europe	911	CYP	Cyprus
						915	UAE	United Arab Emirates


CONTENTS

(1) MAIN FRAME / COVER	2
(2) UPPER SHAFT MECHANISM / NEEDLE BAR / PRESSER FOOT UNIT.....	6
(3) FEED UNIT	8
(4) BOBBIN WINDING MECHANISM / NEEDLE THREADING MECHANISM	10
(5) ELECTRIC PARTS / MAIN MOTOR UNIT	12
(6) ACCESSORY PARTS / USER MANUAL / OTHER PARTS / PACKAGE	14
SPARE PARTS.....	16

Note on parts:

We keep performance parts for this sewing machine for at least 8 years after this model is discontinued.
Performance parts are the necessary parts to maintain the function of the sewing machine.


(1) MAIN FRAME / COVER



(1) MAIN FRAME / COVER

No.	CODE	NAME	REMARKS	No.	CODE	NAME	REMARKS
1	XE6631001	BOBBIN WINDER GUIDE ASSY			XF1589001	DECORATION PLATE A (Style-60e)	1000027303
2	0A5300806	SCREW PAN (S/P WASHER) M3X8			XG7108001	DECORATION PLATE A (FS70)	
3	XE6425104	SPOOL PIN	1000031891		XH1478001	DECORATION PLATE A (FS70WTs)	
3	XG2975001	SPOOL PIN ASSY			XH1483001	DECORATION PLATE A (FS60s)	
4	XE6427001	SPOOL PIN HOLDER			D01GZS001	DECORATION PLATE A (KD40)	
5	XE7218004	SPOOL PIN SUPPORTER	1000031891	30	XE8855001	DECORATION PLATE B (FS40, FS40WT)	
6	XE6633001	SPOOL PIN STOP PLATE			XF0674001	DECORATION PLATE B (ModerN40E)	1000025222
7	XE7626004	SPOOL PIN SPRING COVER	1000031891		XF0690001	DECORATION PLATE B (ModerN50E)	1000025223
8	XE7695004	SPOOL PIN SPRING	1000031891		XF0694001	DECORATION PLATE B (ModerN60E)	1000025224
9	087411416	TAPTITE CUP B M4X14			XF1578001	DECORATION PLATE B (Style-40e)	1000027301
10	XF7875001	BOBBIN PRESSER (FS70, FS40 (888V65), FS70WTs, FS60s)			XF1584001	DECORATION PLATE B (Style-50e)	1000027302
	XE8912001	BOBBIN PRESSER (OTHER)			XF1590001	DECORATION PLATE B (Style-60e)	1000027303
11	0A4302006	SCREW PAN (S/P WASHER) M3X20			XG7109001	DECORATION PLATE B (FS70)	
12	021300106	NUT 1 M3			XH1479001	DECORATION PLATE B (FS70WTs)	
13	XE6429001	THREAD GUIDE PLATE ASSY			XH1484001	DECORATION PLATE B (FS60s)	
14	XE6634001	THREAD GUIDE SUPPORTING PLATE			D01GZR001	DECORATION PLATE B (KD40)	
15	XE7286001	CUTTER COVER ASSY		31	XG1980001	DECORATION COVER L (FS70, FS40 (888V65), FS70WTs, FS60s)	
16	XE6640001	CUTTER COVER			XE6441001	DECORATION COVER (OTHER)	
17	XE6641001	CUTTER HOLDER PLATE		32	085411416	TAPTITE BIND B M4X14	
18	X80321021	NT LOWER THREAD CUTTER		33	XE8856001	SS BUTTON (FS40, FS40WT, ModerN60E, Style-60e, FS70, FS40 (888V65), FS70WTs, FS60s, KD40)	
19	060300416	SCREW BIND M3X4		34	XE6444001	REVERSE BUTTON	
20	085411016	TAPTITE BIND B M4X10		35	XE6446001	NP BUTTON (FS40, FS40WT, ModerN60E, Style-60e, FS70, FS40 (888V65), FS70WTs, FS60s, KD40)	
21	138337022	RUBBER CUSHION A		36	XE6448001	SV KEYTOP (FS40, FS40WT, ModerN60E, Style-60e, FS70, FS40 (888V65), FS70WTs, FS60s, KD40)	
22	026350236	WASHER PLAIN M 3.5		37	XE6500001	SV JOINT PLATE (FS40, FS40WT, ModerN60E, Style-60e, FS70, FS40 (888V65), FS70WTs, FS60s, KD40)	
23	083361216	TAPTITE PAN B M3.5X12		38	XE6449001	SELECTING BUTTON A	
24	XC4077021	BASE PLATE RUBBER		39	XE6450001	SELECTING BUTTON B	
25	XE1372003	SPOOL PRESSER C		40	XE6451001	MANUAL BUTTON A	
26	XE8361001	BELT STOPPER PLATE		41	XE6452001	MANUAL BUTTON B	
27	085411416	TAPTITE BIND B M4X14		42	XE0849001	FRONT COVER THREAD GUARD	
28	XZ5129121	FRONT COVER (FS40, FS40WT)	1000031390	43	XC4077021	BASE PLATE RUBBER	
	XZ5126121	FRONT COVER (ModerN40E, ModerN50E, Style-40e, Style-50e)	1000031390	44	XE2336001	SINGLE LIGHT GUIDE ASSY:M1YM	1000051208
	XZ5130121	FRONT COVER (ModerN60E, Style-60e)	1000031390	45	XE4552001	OPERATION PCB SUPPLY ASSY	
	XG2133001	FRONT COVER (FS70, KD40)		46	XE7607101	SSVR PCB SUPPLY ASSY CP4 (FS40, FS40WT, ModerN60E, Style-60e, FS70, FS40 (888V65), FS70WTs, FS60s)	
	XG2141001	FRONT COVER (FS40 (888V65), FS70WTs, FS60s)					
29	XE8854001	DECORATION PLATE A (FS40, FS40WT)					
	XF0673001	DECORATION PLATE A (ModerN40E)	1000025222				
	XF0689001	DECORATION PLATE A (ModerN50E)	1000025223				
	XF0693001	DECORATION PLATE A (ModerN60E)	1000025224				
	XF1577001	DECORATION PLATE A (Style-40e)	1000027301				
	XF1583001	DECORATION PLATE A (Style-50e)	1000027302				


(1) MAIN FRAME / COVER



(1) MAIN FRAME / COVER

No.	CODE	NAME	REMARKS
	XE7606101	SSVR PCB SUPPLY ASSY CP4L (OTHER)	
47	XE7595101	LED LAMP SUPPLY ASSY CP4	
48	085311016	TAPTITE BIND B M3X10	
49	X53169020	BAND	
50	XZ5049001	GIZA TITE (S/P W) 5X18	
51	XE2261001	GIZA TITE (S/P W) 4X25	
52	XG9430001	GIZA TITE 4X12	
53	XC7566051	SCREW, PAN(S/P WASHER) M4X8	
54	XG0646001	FACE PLATE	
55	XA3337022	TAPTITE,CUP P M4X20	
56	XG0650001	ACCESSORY TABLE	
57	XG9981001	NEEDLE PLATE B ASSY (ModerN40E, ModerN50E, ModerN60E, Style-40e, Style-50e, Style-60e, FS70, FS70WTs, FS60s, KD40)	1000058401
	XG9980001	NEEDLE PLATE B ASSY (FS40 (888V65))	
58	XE8743001	NEEDLE PLATE B ASSY (FS40, FS40WT)	
59	XE6457001	NEEDLE PLATE B (ModerN40E, ModerN50E, ModerN60E, Style-40e, Style-50e, Style-60e, FS70, FS70WTs, FS60s, KD40)	1000025222
60	XE8744001	NEEDLE PLATE B (FS40, FS40WT)	
61	XC7371022	SLIDE BUTTON	
62	XD1666052	CUTTER COVER (ModerN40E, ModerN50E, ModerN60E, Style-40e, Style-50e, Style-60e, FS70, FS70WTs, FS60s)	1000025222
	XE6640001	CUTTER COVER (FS40, FS40WT)	
63	XC2368121	SPRING PLATE	1000031909
64	X80321021	NT LOWER THREAD CUTTER (EXCPET: FS40, FS40WT)	1000025222
65	XH1054001	NEEDLE PLATE COVER SUPPLY ASSY	
66	XE7163001	SLIDE BUTTON B	
67	XG1981001	BASE COVER	
68	085411016	TAPTITE BIND B M4X10	
69	XG0196001	LOWER THREADING LABEL (FS40, FS40WT)	1000043362
70	XG0195001	LOWER THREAD GUIDE LABEL (ModerN40E, ModerN50E, ModerN60E, Style-40e, Style-50e, Style-60e, FS70, FS70WTs, FS60s, KD40)	1000043034


(2) UPPER SHAFT MECHANISM / NEEDLE BAR / PRESSER FOOT UNIT



(2) UPPER SHAFT MECHANISM / NEEDLE BAR / PRESSER FOOT UNIT

No.	CODE	NAME	REMARKS	No.	CODE	NAME	REMARKS
UPPER SHAFT MECHANISM				42	XC3037021	SCREW3X10	
1	XH3275101	UPPER SHAFT SUPPLY ASSY CP4		43	XC8765121	SHAFT	
2	XC3529023	PULLEY (FS70WTs, FS60s)		44	XZ5030001	WASHER, SPRING	
	XC3529021	PULLEY (OTHER)		45	048050346	RETAINING RING E5	
3	012500532	SET SCREW SOCKET (FT) M5X5		46	XC3338021	SCREW 3X8	
4	XC3534121	UPPER SHAFT BEARING PRESSER		47	XC8564031	THREAD TAKE-UP LEVER	
5	XG9429001	GIZA TITE 5X16		48	XC4897020	THREAD TAKE-UP LEVER LINK	
6	XG3557001	T BELT 420-5GT-6	1000058414	49	XC4898021	PRESSER BAR	
7	XG4071201	TENSION PULLEY ASSY		50	XC4899121	PRESSER BAR CLAMP	
8	0A4400806	SCREW PAN (S/P WASHER) M4X8		51	XC7207021	SCREW STUD M5	
9	XC8739120	TENSION PULLEY HOLDER	1000056302	52	XC4900021	SPRING	
NEEDLE BAR / PRESSER FOOT UNIT				53	XE2555101	PRESSER FOOT HOLDER ASSY	
10	XC8741121	BASE HOLDER ASSY		54	XG1343001	SCREW SM3.57-40X8	1000052522
11	XE8695101	NEEDLE BAR SUPPORTER ASSY	1000056821	55	XZ5134001	Z FOOT	1000031539
12	XC2420020	SHAFT		56	XC4902021	PRESSER FOOT LIFTER	
13	XC8754021	NEEDLE HOLDER SHAFT A		57	048040346	RETAINING RING E4	
14	014300532	SET SCREW SOCKET (CP) M3X5		58	XC8766020	THREAD RELEASE LEVER	
15	XC8755020	PLATE		59	XC4904121	SPRING	
16	060300516	SCREW BIND M3X5		60	146200021	RETAINING RING, CS4	
17	X50476021	SPRING		61	XF9982101	BH SWITCH ASSY	
18	XG7581001	NEEDLE BAR ASSY N	1000055989	62	0A4400806	SCREW PAN (S/P WASHER) M4X8	
19	XE3827001	NEEDLE CLAMP SCREW		63	XC8773020	RUBBER	
20	XF4780101	NEEDLE THREAD BLOCK	1000038237	64	XC8774021	PRESSER SWITCH HOLDER	
21	XF5017001	NEEDLE BAR CRANK ROD ASSY	1000032403	65	XC8775021	PF SWITCH ASSY, LE	
22	132051022	SCREW, FLAT SM3.57-40X7 L		66	X53169020	BAND	
23	012400432	SET SCREW SOCKET (FT) M4X4		67	X53330020	WASHER	1000025734
24	XA1854051	THREADER HOOK ASSEMBLY		68	XE3856001	LEAD WIRE ASSY: GROUND	
25	XC2429021	SPRING		69	XG9432001	GIZA TITE 5X20	
26	X56851021	LOCK NUT		70	XC4905121	ADJUSTING SCREW	
27	014401232	SET SCREW SOCKET (CP) M4X12		71	060302506	SCREW BIND M3X25	
28	XC8756121	SHAFT BUSHING		72	XC6056120	PLATE SPRING	
29	060300616	SCREW BIND M3X6		73	XC4906020	ADJUSTING PLATE	
30	XC8757021	Z PULSE MOTOR: M35SP-9N		74	085411016	TAPTITE BIND B M4X10	
31	XC8759021	LEAD WIRE ASSY, ZPM-LE		75	XC4907021	LABEL	
32	XC8760020	Z ZIGZAG CAM		76	XF4779101	NEEDLE THREAD GUIDE PLATE	1000038237
33	XC8761121	Z ZIGZAG LEVER ASSY		77	XZ5106201	SCREW. M2.6	1000038237
34	XC8764020	Z LEVER CAP		78	XG3666001	NEEDLE UNIT SUPPLY ASSY CP4 (FS40 (888V65))	
35	137713020	POLYESTER SLIDER			XG3670001	NEEDLE UNIT SUPPLY ASSY CP4 (OTHER)	1000051160
36	XC2435020	ZIGZAG ADJUSTING NUT		79	060400616	SCREW BIND M4X6	
37	018301032	BOLT SOCKET M3X10					
38	048030346	RETAINING RING E3					
39	XC2748021	SPRING-Z					
40	XC2436021	NEEDLE HOLDER BLOCK					
41	XC2437021	SHAFT ASSY					


(3) FEED UNIT



(3) FEED UNIT

No.	CODE	NAME	REMARKS	No.	CODE	NAME	REMARKS
1	XE6467201	BASE PLATE ASSY	1000033187	42	XF8039001	SHAFT SUPPORTER	1000048616
2	XE5656001	FEED ARM SUPPORTER		43	0A4400806	SCREW PAN (S/P WASHER) M4X8	
3	XE7489201	FEED DOG	1000049231	44	014400432	SET SCREW SOCKET (CP) M4X4	
4	060300616	SCREW BIND M3X6		45	014400632	SET SCREW SOCKET (CP) M4X6	
5	XE2015201	FEED BAR ASSY		46	XE7558001	INNER ROTARY HOOK BRACKET ASSY	
6	137999020	POLYESTER SLIDER		47	0A5300806	SCREW PAN (S/P WASHER) M3X8	
7	146200021	RETAINING RING, CS4		48	XE7323101	IRH BRACKET SUPPORT PLATE	
8	XC8789121	HORIZONTAL FEED SHAFT	1000032545	49	XC8796021	LOWER SHAFT ASSY	
9	130676121	SET SCREW COLLAR		50	XC4943021	TIMING PULLEY D	
10	X50546020	WASHER,THRUST		51	014500532	SET SCREW SOCKET (CP) M5X5	
11	060301206	SCREW BIND M3X12		52	XH4997001	LOWER SHAFT BUSHING	
12	XG8343001	FEED ARM B ASSY		53	XH4225001	UPPER SHAFT BUSHING	
13	XC4927021	FEED SUPPORTING PLATE		54	X51383020	WASHER,THRUST	
14	XC4928120	FEED SUPPORTING PLATE B		55	048060346	RETAINING RING E6	
15	XC2527121	FEED ADJUSTER		56	XC8798021	SET COLLAR	
16	XC2529020	F GEAR		57	XC4944021	BUSHING PRESSER B	
17	XH2489001	SPRING		58	085310616	TAPTITE BIND B M3X6	
18	137713020	POLYESTER SLIDER		59	XE6468101	NEEDLE PLATE A ASSY	1000028832
19	XC2531021	SPRING		60	XE6469001	NEEDLE PLATE A	
20	XC8791121	FPM HOLDER SUB ASSY	1000038228	61	XF2440001	STOPPER PLATE	1000028832
21	XC8757021	Z PULSE MOTOR:M35SP-9N		62	XE7164001	NEEDLE PLATE B SUPPORT PLATE	
22	XC8793021	LEAD WIRE ASSY,FPM-LE		63	XE6471001	F GEAR STOPPER PLATE	
23	XC8773020	RUBBER		64	XE6472001	NEEDLE PLATE HOLDER	1000029081
24	060300416	SCREW BIND M3X4		65	060260316	SCREW BIND M2.6X3	
25	XE6639001	SCREW3X8		66	XE6473001	SCREW NEEDLE PLATE	
26	018402532	BOLT SOCKET M4X25	1000051398	67	X56655021	RETAINING RING: CSTW-3.5	
27	XC2537021	SPRING		68	XE1478101	SPRING	1000025521
28	XC9924021	RETAINING RING 10		69	XC3534121	UPPER SHAFT BEARING PRESSER	
29	XC3941021	VERTICAL ADJUSTER SCREW ASSY		70	XG9429001	GIZA TITE 5X16	
30	XC2546121	M5 NUT	1000042713	71	XE7756101	INNER ROTARY HOOK ASSY	
31	XE1940001	SPRING		72	XG6924001	PILE	1000055383
32	XC8794021	VERTICAL FEED SHAFT		73	X52800120	BOBBIN	
33	XC2551020	VERTICAL LEVER		74	XG9431001	GIZA TITE 5X16	
34	025040336	WASHER PLAIN L 4		75	XZ5053001	WASHER EX TOOTH 5	
35	XC8795121	DROP KNOB		76	XE8564001	UNIT WASHER	
36	XC2550021	SPRING		77	060300816	SCREW BIND M3X8	
37	048030346	RETAINING RING E3		78	XG3788001	WASHER PLAIN M 3	1000051222
38	XE9837001	OUTER ROTARY HOOK ASSY (FS40 (888V65): NEU, FS70WTs, FS60s , KD40)		79	XG1797001	FEED DOG SUPPLY ASSY	1000046307
	XD0115021	OUTER ROTARY HOOK ASSY (OTHER)		80	XH1097101	FEED UNIT SUPPLY ASSY CP4	
39	XD1943021	OUTER ROTARY HOOK SHAFT					
40	137805022	SPACER					
41	XG8725001	WASHER 6					


(4) BOBBIN WINDING MECHANISM / NEEDLE THREADING MECHANISM



(4) BOBBIN WINDING MECHANISM / NEEDLE THREADING MECHANISM

[illegible]


(5) ELECTRIC PARTS / MAIN MOTOR UNIT



(5) ELECTRIC PARTS / MAIN MOTOR UNIT

[illegible]







(6) ACCESSORY PARTS / USER MANUAL / OTHER PARTS / PACKAGE



(6) ACCESSORY PARTS / USER MANUAL / OTHER PARTS / PACKAGE

No.	CODE	NAME	REMARKS	No.	CODE	NAME	REMARKS
ACCESSORY PARTS							
1	XC1074051	DISC-SHAPED SCREWDRIVER			XG9949001	INSTRUCTION BOOK DAN/NOR (Danish, Norwegian)	
2	X59370021	ZIPPER FOOT			XG9681001	INSTRUCTION BOOK SWE/FIN (Swedish, Finnish)	
3	XC2691133	BH PRESSER FOOT ASSY			XG8103101	INSTRUCTION BOOK KR (Korean)	
4	XD0810031	TRANSPARENCY PRESSER FOOT			XG2854001	INSTRUCTION BOOK ARB (Arabic)	
5	X52800120	BOBBIN		33	XE8768001	INSTRUCTION DVD PAL	
6	131096121	NEEDLE SET (1 PCE)			XE6308001	INNOV-IS RANGE PROMOTION DVD	
7	XC8834021	NEEDLE SET		34	XE8765001	QUICK REFERENCE GUIDE (ModerN40E, ModerN50E, Style-40e, Style-50e, FS70WTs, FS60s)	1000025222
8	XD0360021	NEEDLE SET G			XE8764001	QUICK REFERENCE GUIDE (ModerN60E, Style-60e, FS70, KD40)	
9	XC4487021	ACCESSORY BAG			XE8766001	QUICK REFERENCE GUIDE (OTHER)	
10	XC3098031	OVERCASTING STITCH FOOT ASSY	1000040710	35	130800021	BAG 230X310H	
11	XE2650001	BLIND STITCH FOOT ASSY	1000036936	36	XD0120021	CAUTION SHEET S33	
12	XF4967001	RIPPER ASSY (FS70)		37	XF0300101	INSERTION WEEE	1000034540
	XZ5082001	SEAM RIPPER (OTHER)		38	XE9897001	UKRAINIAN ROHS INSERTION (RUS)	1000025222
13	X59476051	CLEANING BRUSH		39	XF5734001	CE INSERTION 2	1000034881
14	XE2137001	BUTTON SEWING FOOT			XH3846101	CE INSERTION 3	
15	130012027	SPOOL PRESSER A			D01EVG001	FINGER GUARD INSERTION	
16	130013126	SPOOL PRESSER B			XG3932001	SUITABLE AGE INSERTION	
17	XE2241002	EXTRA SPOOL PIN		40	XA2112022	DUST COVER ASSY	
18	XA2112022	DUST COVER ASSY		PACKAGE			
19	XG3632101	LE WIDE TABLE ASSY US (FS40WT, FS70WTs)	1000048613	41	XE8857001	COLOR CARTON FS-40 (FS40)	
20	XC9357121	WIDE TABLE SUB ASSY (FS40WT, FS70WTs)			XE9402001	CARTON MODEL:FS-40WT (FS40WT)	
21	XC9360021	FIXING PLATE A (FS40WT, FS70WTs)			XF0682001	COLOR CARTON MODERN40E (ModerN40E)	1000025222
22	XC4495022	TABLE FOOT (FS40WT, FS70WTs)			XF0686001	COLOR CARTON MODERN50E (ModerN50E)	1000025223
23	XD1223021	ADJUSTING FOOT (FS40WT, FS70WTs)			XF0695001	COLOR CARTON MODERN60E (ModerN60E)	1000025224
24	021400206	NUT 2 M4 (FS40WT, FS70WTs)			XF1580001	COLOR CARTON MODEL:STYLE-40E (Style-40e)	1000027301
25	087411416	TAPTITE CUP B M4X14 (FS40WT, FS70WTs)			XF1586001	COLOR CARTON MODEL:STYLE-50E (Style-50e)	1000027302
26	X59853020	RUBBER CUSHION (FS40WT, FS70WTs)			XF1592001	COLOR CARTON MODEL:STYLE-60E (Style-60e)	1000027303
27	X61231021	BAG 400X500H (FS40WT, FS70WTs)			XG7111001	COLOR CARTON MODEL:FS70 (FS70)	
28	XC9361020	LE WIDE TABLE CARTON (FS40WT, FS70WTs)			XG8089001	CARTON MODEL:FS-40 (FS40: RUS)	
29	XC9362120	PAD (FS40WT, FS70WTs)	1000031976		XG8233001	COLOR CARTON MODEL:FS70	
30	XC9802021	INSTRUCTION MANUAL (FS40WT, FS70WTs)			XG1938001	COLOR CARTON MODEL:FS-40 (FS40 (888V65): NEU)	
31	XD1819121	QUILTING FOOT (FS70WTs)			XH1475101	CARTON MODEL:FS70WTs (FS70WTs)	
	XH2604001	QUILTING FOOT (FS70WTs: NEU)			XH1486101	CARTON MODEL:FS60S (FS60s)	
					D01GZV001	COLOR CARTON MODEL:KD4 (KD40)	
46	D01EG7001	FINGER GUARD		42	XE6535401	POLYSTYRENE FORM ASSY V61	1000031942
USER MANUAL / OTHER PARTS				43	X60439151	BAG 630X630T	1000051639
32	XG7575101	INSTRUCTION BOOK ENG (English)		44	XE5049001	NEEDLE GUARD D	
	XG7495101	INSTRUCTION BOOK GER (German)		45	XC9354020	PAD D (FS40WT, FS70WTs)	
	XG7576101	INSTRUCTION BOOK FRE (French)					
	XG7496101	INSTRUCTION BOOK DUT (Dutch)					
	XG7497101	INSTRUCTION BOOK ITA (Italian)					
	XE8760101	INSTRUCTION BOOK SPA (Spanish)					
	XG9605001	INSTRUCTION BOOK RUS (Russian)					

SPARE PARTS



SPARE PARTS

[illegible]

* USA must purchase in the US. (It's not listed on the TSCA).

brother