


E-8 Carburetor (1)




E-8 Carburetor (1)


Ref. No.	Part No.	Description	Reqd. No.	No. Used on		News No.
				From	To	
	16100-044-681	CARBURETOR ASSY.....	1	P50-A100001	 P50-A148606	
	16100-044-691	CARBURETOR ASSY..... (Used in Netherland)	1	P50-A128651		
1	16194-044-004	CAP, cable	1	P50-A100001		
2	16118-044-004	ADJUSTER, cable	1	P50-A100001		
3	16119-044-004	TOP.....	1	P50-A100001		
4	16171-044-004	WASHER, top	1	P50-A100001		
5	16185-044-004	SPRING, throttle	1	P50-A100001		
6	16156-044-004	PLATE, needle clip	1	P50-A100001		
7	16157-044-004	CLIP, needle	1	P50-A100001		
8	16151-044-681	NEEDLE, jet	1	P50-A100001	 P50-A148606	
9	16141-044-681	VALVE, throttle	1	P50-A100001	 P50-A148606	
10	16193-044-004	SUPPORT, cable	1	P50-A100001		
11	16125-044-004	VALVE SET, float	1	P50-A100001		
12	16173-044-004	O RING, 8 ϕ	1	P50-A100001		
13	16188-044-004	WASHER, fiber	1	P50-A100001		
14	16139-027-004	HOLDER, needle jet	1	P50-A100001	 P50-A148606	
15	16175-001-004	O RING, 4.5 ϕ	1	P50-A100001		
16	16133-044-681	JET, needle	1	P50-A100001	 P50-A148606	
17	99144-03504	JET, slow (# 35)	1			
	99144-03804	JET, slow (# 38)	1			
18	16163-044-004	SCREW, throttle stop	1	P50-A100001	 P50-A148606	
19	16162-259-004	SCREW, air	1	P50-A100001		
20	16173-260-004	O RING, 2.8 ϕ	3	P50-A100001		
21	16182-011-004	SPRING, throttle stop	1	P50-A100001		
22	16181-202-004	SPRING, air screw	1	P50-A100001		
23	16124-044-004	COVER, oil chamber	1	P50-A100001	 P50-A148606	
24	16123-044-004	PACKING, oil chamber	1	P50-A100001	 P50-A148606	
25	99120-04504	JET, main (# 45)	1	P50-A100001	 P50-A148606	
	99120-04804	JET, main (# 48)	1	P50-A100001	 P50-A148606	
	99120-05004	JET, main (# 50)	1	P50-A100001	 P50-A148606	
	99120-05204	JET, main (# 52)	1	P50-A100001	 P50-A148606	
	99120-05504	JET, main (# 55)	1	P50-A100001	 P50-A148606	

E-8 Carburetor (1)

Ref. No.	Part No.	Description	Reqd. No.	No. Used on		News No.
				From	To	
	99120-05804	JET, main (# 58)	1	P50-A100001	P50-A148606	
	99120-06004	JET, main (# 60)	1	P50-A100001	P50-A148606	
	99114-044-0501	JET, main (# 50) (Used in Netherland) ...	1	P50-A128651		
	99114-044-0521	JET, main (# 52) (Used in Netherland) ...	1	P50-A128651		
	99114-044-0551	JET, main (# 55) (Used in Netherland) ...	1	P50-A128651		
	99114-044-0581	JET, main (# 58) (Used in Netherland) ...	1	P50-A128651		
	99114-044-0601	JET, main (# 60) (Used in Netherland) ...	1	P50-A128651		
	99114-044-0621	JET, main (# 62) (Used in Netherland) ...	1	P50-A128651		
	99114-044-0651	JET, main (# 65) (Used in Netherland) ...	1	P50-A128651		
	99114-044-0681	JET, main (# 68) (Used in Netherland) ...	1	P50-A128651		
26	16112-044-004	COVER, float chamber	1	P50-A100001	P50-A148606	
27	16174-044-004	O RING, 40.5 ϕ	1	P50-A100001		
28	16122-044-004	FLOAT	1	P50-A100001	P50-A148606	
29	93500-04008	SCREW, cross, 4 $\times$ 8	1			
30	93600-04008	SCREW, cross, 4 $\times$ 8	4			
31	94111-04000	WASHER, spring, 4 mm	1			







E-8 Carburetor (2)

Ref. No.	Part No.	Description	Reqd. No.	No. Used on		News No.
				From	To	
	16100-044-683	CARBURETOR ASSY.....	1	P50-A148607.....		
1	16194-044-004	CAP, cable	1	P50-A100001.....		
2	16118-044-004	ADJUSTER, cable	1	P50-A100001.....		
3	16119-044-004	TOP.....	1	P50-A100001.....		
4	16171-044-004	WASHER, top	1	P50-A100001.....		
5	16185-044-004	SPRING, throttle	1	P50-A100001.....		
6	16156-044-004	PLATE, needle clip	1	P50-A100001.....		
7	16157-044-004	CLIP, needle	1	P50-A100001.....		
8	16151-044-683	NEEDLE, jet	1	P50-A148607.....		
9	16141-044-683	VALVE, throttle	1	P50-A148607.....		
10	16139-044-004	HOLDER, needle jet	1	P50-A148607.....		
11	16175-001-004	O RING, 4.5 ϕ	1	P50-A100001.....		
12	16133-044-683	JET, needle	1	P50-A148607.....		
13	99144-03514	JET, slow (# 35)	1			
	99144-03814	JET, slow (# 38)	1			
14	16163-044-014	SCREW, throttle stop	1	P50-A148607.....		
15	16162-044-004	SCREW, air	1	P50-A148607.....		
16	16173-260-004	O RING, 2.8 ϕ	3	P50-A100001.....		
17	16182-011-004	SPRING, throttle stop	1	P50-A100001.....		
18	16181-202-004	SPRING, air screw.....	1	P50-A100001.....		
19	99120-05514	JET, main (# 55)	1			
	99120-05814	JET, main (# 58)	1			
	99120-06014	JET, main (# 60)	1			
20	16112-044-014	COVER, float chamber	1	P50-A148607.....		
21	16174-044-004	O RING, 40.5 ϕ	1	P50-A100001.....		
22	16122-044-014	FLOAT	1	P50-A148607.....		
23	16189-044-004	WASHER, fiber, 4 mm	1	P50-A148607.....		
24	93500-03008	SCREW, cross, 3x8	2			
25	93500-04008	SCREW, cross, 4x8	1			
26	94111-03000	WASHER, spring, 3 mm	2			